






1x

1




4x

2






3





4






1x

5



1x

6




4x




2x

7



2x

8






2x



1x

9




1x



2x


10







1x

11



2x


12





1x

13




1x




1x




1x



14






1x




15




2x

16



2x

17






1x

1




1x

2



1x

3





1x

4



1x



1x




1x




1x

5






6




18



6x


6x

19







2x



20



21



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346

LEGO, the LEGO logo and MIXELS are trademarks and/or copyrights of the/sont des marques de commerce et/ou copyrights du/son marcas registradas, algunas de ellas protegidas por derechos de autor, de LEGO Group. ©2014 The LEGO Group. All rights reserved/Tous droits réservés/Todos los derechos reservados.